



LAMAX NoiseComfort ANC Headphones User Guide

[Home](#) » [LAMAX](#) » LAMAX NoiseComfort ANC Headphones User Guide 

Contents

- [1 LAMAX NoiseComfort ANC Headphones](#)
- [2 Controls](#)
- [3 INSTRUCTION](#)
- [4 Parameters](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

LAMAX

LAMAX NoiseComfort ANC Headphones



Controls

On	Hold  for 2 seconds
Off	Hold  for 5 seconds
Activate ANC	Press 
Play / Pause	Press 
Next / Previous Track	Hold  / hold 
VOL + / VOL -	Press  / press 
Answer / End Call	Press 
Reject Call	Hold  for 1 second
Activate Mobile Assistant	Press  twice

INSTRUCTION

Turning On

Press for 2 seconds to turn on the headphones. This is accompanied by an audible notification and the blue LED lights up.

Pairing

1. The headphones automatically go into pairing mode the first time you turn them on. This is indicated by the LED alternately flashing red and blue.
2. On your device, turn Bluetooth on and locate and select LAMAX NoiseComfort ANC in the list of available Bluetooth devices. After successfully pairing, there is an audible notification.

If you have trouble pairing, remove your headphones from the list of paired devices in your smartphone. Turn off the headphones and then hold the  button for 5 seconds. The headphones turn on and automatically go into pairing mode. Pair the headphones again as in Step 2 above.

Active Noise Cancellation (ANC)

Press the ANC button to turn  on. When ANC is on, the green LED next to the charging connector is lit. To turn off ANC, press the  button again:

The ANC function cannot be activated if an audio cable is connected.

ANC especially suppresses deeper frequencies. Human voices and higher frequencies are minimally suppressed.

Turning Off

Press and hold the  for 5 seconds to turn off the headphones.

Charging

To charge, connect the USB-C cable to the headphones and the other end to the 5V USB charger. The LED lights up red when charging and blue when fully charged.

Parameters

Wireless technology _____	Bluetooth 5.0 _____
Bluetooth range _____	up to 10 metres _____
Supported codecs _____	AAC, SBC _____
Battery capacity _____	1050 mAh _____
Headphone charging time _____	3 hours _____
Playback time _____	up to 50 hours _____
Playback time with ANC _____	up to 26 hours _____
Weight _____	260 g _____

Subject to printing errors.

The latest version of the user guide can be downloaded here:

<https://www.lamax-electronics.com/downloads/lamax-noisecomfortanc/manual>

Documents / Resources

	LAMAX NoiseComfort ANC Headphones [pdf] User Guide NoiseComfort ANC, Headphones, NoiseComfort ANC Headphones
---	---

References

-  [LAMAX Electronics | EN](#)